

CHECKLIST

Evening Shutdown

- 1 Locate and identify any RUSH jobs for the next day.
- 2 Put away unused baskets.
- 3 Turn ovens down 40°C.
- 4 Shut down ultrasonic, drain tanks and wipe them with IPA.
- 5 Stack and put away fixtures and rings.
- 6 Blast dirty sectors. Clean with acetone, store in sealed container.
- 7 Blast crucible liners and shutters.
- 8 Wipe down all surfaces.
- 9 Vacuum or mop floors and pull up-sticky mats.
- 10 Empty trash cans.
- 11 Prep area & chemicals for next run.

The best lab procedures, equipment, and materials are key to high quality lens coatings. Along with strict cleaning and maintenance, following standard operating procedures minimizes the chance of down-time or compromising the quality of coatings.

Questions? Call the Q at

888.214.7932

Quantum Innovations, Inc.
549 E Vilas Rd.
Central Point, OR 97502
888.214.7932
technicalsupport@Qtmi.net

QUANTUM
Qtmi.net

