CHECKLIST

- Work in the flow booth when inspecting and fixtuing lenses to lessen the possibility of airborne contaminants getting on lenses.
- Only lenses, trays, fixtures and lint-free wipes or cleaning cloths should should be placed or used in the flow booth.
- It is recommended that the flow booth remain on 24 hours per day for airflow and cleanliness.
- KEEP CLEAN! ALL SURFACES of the flow booth must be free from dirt and dust.
- NEVER place food or drink on flow booth surfaces or in lab!
- NEVER place paper, cell phones or personal items in the flow booth!
- NEVER leave lenses outside of the flow booth!
- NEVER turn off the fan while lenses present!
- Monthly clean and inspect emitter point of anti-static gun.
- Check prefilters quarterly: change filters at least yearly (booth and anti-static gun).

The best lab procedures, equipment, and materials are key to high quality lens coatings. Along with strict cleaning and maintenance, following standard operating procedures minimizes the chance of down-time or compromising the quality of coatings.

Questions? Call the Q at

1

888.214.7932

Quantum Innovations, Inc. 549 E Vilas Rd. Central Point, OR 97502 888.214.7932 technicalsupport@Qtmi.net



